

# Installation Instructions for Open-Wound Centry Cover

## Step 1

Your Open-Wound Cover is compressed under spring pressure! Hold it securely while counting the retaining band(s) and release it carefully on a horizontal surface. Installing a horizontally mounted pole through cover's bore affords the most protection against the cover becoming uncontrollable.

The product label is on the outside of the topmost coil and must never be coiled inside.

Open-wound covers are to be installed with the large end at the top, for vertical use, and the exposed edges of the coils away from the direction of debris flow in horizontal applications.



## Step 2

Step 2: Opening small end to expand over shaft or screw.

## Step 3

Install the Open Wound cover by placing the second opening from the small (unlabeled) end over the shaft.



## Step 4

Wind the cover on clockwise (from the large end) until the entire cover encompassed the shaft.

## Step 5

Reverse the winding operation (counter-clockwise from the large end) and assemble the cover with the innermost coil inside and stack each succeeding, larger coil until entire cover is in place.

By hand, turn the coils as required to obtain uniform movement of the coils over each other. Compress and extend the cover by hand – maintaining approximate parallelism of the end surfaces.



## Step 6

Be certain that the functional characteristics have been restored  
Your cover is now ready to be put into operation.